

165XB Electrical Installation Tester

Users Manual

LIMITED WARRANTY AND LIMITATION OF LIABILITY

Each Fluke product is warranted to be free from defects in material and workmanship under normal use and service. The warranty period is three years and begins on the date of shipment. Parts, product repairs, and services are warranted for 90 days. This warranty extends only to the original buyer or end-user customer of a Fluke authorized reseller, and does not apply to fuses, disposable batteries, or to any product which, in Fluke's opinion, has been misused, altered, neglected, contaminated, or damaged by accident or abnormal conditions of operation or handling. Fluke warrants that software will operate substantially in accordance with its functional specifications for 90 days and that it has been properly recorded on non-defective media. Fluke does not warrant that software will be error free or operate without interruption.

Fluke authorized resellers shall extend this warranty on new and unused products to enduser customers only but have no authority to extend a greater or different warranty on behalf of Fluke. Warranty support is available only if product is purchased through a Fluke authorized sales outlet or Buyer has paid the applicable international price. Fluke reserves the right to invoice Buyer for importation costs of repair/replacement parts when product purchased in one country is submitted for repair in another country.

Fluke's warranty obligation is limited, at Fluke's option, to refund of the purchase price, free of charge repair, or replacement of a defective product which is returned to a Fluke authorized service center within the warranty period.

To obtain warranty service, contact your nearest Fluke authorized service center to obtain return authorization information, then send the product to that service center, with a description of the difficulty, postage and insurance prepaid (FOB Destination). Fluke assumes no risk for damage in transit. Following warranty repair, the product will be returned to Buyer, transportation prepaid (FOB Destination). If Fluke determines that failure was caused by neglect, misuse, contamination, alteration, accident, or abnormal condition of operation or handling, including overvoltage failures caused by use outside the product's specified rating, or normal wear and tear of mechanical components, Fluke will provide an estimate of repair costs and obtain authorization before commencing the work. Following repair, the product will be returned to the Buyer transportation prepaid and the Buyer will be billed for the repair and return transportation charges (FOB Shipping Point).

THIS WARRANTY IS BUYER'S SOLE AND EXCLUSIVE REMEDY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. FLUKE SHALL NOT BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OR LOSSES, INCLUDING LOSS OF DATA, ARISING FROM ANY CAUSE OR THEORY.

Since some countries or states do not allow limitation of the term of an implied warranty, or exclusion or limitation of incidental or consequential damages, the limitations and exclusions of this warranty may not apply to every buyer. If any provision of this Warranty is held invalid or unenforceable by a court or other decision-maker of competent jurisdiction, such holding will not affect the validity or enforceability of any other provision.

Fluke Corporation P.O. Box 9090 Everett, WA 98206-9090 U.S.A. Fluke Europe B.V. P.O. Box 1186 5602 BD Eindhoven The Netherlands

Table of Contents

Title	Page
Introduction	1
How to Contact Fluke	1
Unpacking the Tester	2
Operating the Tester	
Using the Rotary Switch	4
Understanding the Pushbuttons	5
Understanding the Display	7
Input Terminals	12
Using the IR Port (Model 1653B Only)	12
Error Codes	13
Power-On Options	14
Making Measurements	15
Measuring Volts and Frequency	15
Measuring Insulation Resistance	16
Measuring Continuity	17
Measuring Loop/Line Impedance	18
Loop Impedance (Line to Protective Earth L-PE)	18
Earth Resistance Testing by Loop Method	21
Line Impedance	21
Measuring RCD Tripping Time	24
Measuring RCD Tripping Current (Models 1652B	
and 1653B Only)	27
RCD Testing in IT Systems	29
Measuring Earth Resistance (Model 1653B Only)	30
Testing Phase Sequence (Model 1653B Only)	31
Storing and Recalling Measurements	
Using Memory Mode	32
Storing a Measurement	33
Recalling a Measurement	33
Clearing Memory	
Uploading Test Results (Model 1653B Only)	
Maintaining the Tester	35

Cleaning	35
Testing and Replacing the Batteries	35
Testing the Fuse	36
Specifications	37
Features by Model	37
General Specifications	38
Electrical Measurement Specifications	39
Insulation Resistance (R _{ISO})	39
Continuity (R ₁₀)	40
Loop Tests (Z)	40
RCD/FI Tests ($_{\Delta}$ T, I $_{\Delta}$ N)	41
Earth Tests (R _F)	42
AC Voltage Measurement (V)	42
Continuity Testing (R _{I O})	42
Insulation Resistance Measurement (R _{ISO})	43
Loop and Line Impedance (Z)	44
No Trip and Hi Current Modes RCD/FI	44
Prospective Earth Fault Current Test (PSC/I _k)	44
RCD Testing	45
RCD Types Tested	45
Test Signals	45
Tripping Speed Test (AT)	45
Maximum Trip Time	46
RCD/FI-Tripping Current Measurement/Ramp Test (I _{AN})	46
Earth Resistance Test (R _F)	47
Phase Sequence Indication	47
Mains Wiring Test	48
Operating Ranges and Uncertainties per EN 61557	48
Operating Uncertainties per EN 61557	

List of Tables

Table	Title	Page
1.	Standard Accessories	. 2
2.	Country Specific Mains Cords	. 3
3.	Rotary Switch	. 4
4.	Pushbuttons	. 5
5.	Display Features	. 7
6.	Error Codes	. 13
7.	Power-On Options	. 14

165XB

Users Manual

List of Figures

Figure	Title	Page
1.	Rotary Switch	4
2.	Pushbuttons	5
3.	Display Features	7
4.	Input Terminals	
5.	Error Display	13
6.	Lead Swapping Modes	
7.	Volts Display/Switch and Terminal Settings	
8.	Insulation Resistance Display/Switch and Terminal Settings	16
9.	Continuity and Continuity Zero Display/Switch and	
	Terminal Settings	17
10.	Loop/Line Impedance/Switch and Terminal Settings	
11.	Display After Zeroing	
12.	3-Wire Connection for Earth Resistance Loop Test	
13.	Line Impedance Display	
14.	Measuring in a 3-Phase System	
15.	RCD Tripping Time Display/Switch and Terminal Settings	
16.	RCD Tripping Current/Switch and Terminal Settings	
17. 18.	Connection for RCD Testing on IT Electrical Systems	
18. 19.	Earth Resistance Display/Switch and Terminal Settings Earth Resistance Test Connection	
19. 20.	Phase Sequence Display/Switch and Terminal Settings	
20. 21.	Phase Sequence Test Connection	
21. 22.	Attaching the IR Adapter	
23.	Replacing the Batteries	
۷۵.	riepiading the Datteries	50

∧ Marnings: Read Before Using

To avoid possible electric shock or personal injury:

- Use the tester only as specified in this manual, or the protection provided by the tester might be impaired.
- Do not use in a damp or wet environment.
- Inspect the tester before using it. Do not use the tester if it appears damaged. Look for cracks or missing plastic. Pay particular attention to the insulation around the connectors.
- Inspect the test leads before use. Do not use them if insulation is damaged or metal is exposed. Check the test leads for continuity. Replace damaged test leads before using the tester. Use only test leads specified in the manual or safety may be impaired.
- Verify the tester's operation by measuring a known voltage before and after using it.
 Do not use the tester if it operates abnormally. Protection may be impaired. If in doubt, have the tester serviced.
- Have the tester serviced only by qualified service personnel.
- Do not apply more than the rated voltage, as marked on the tester, between the terminals or between any terminal and earth ground.
- Remove test leads from the tester before opening the tester case.
- Never operate the tester with the case open.
- Use caution when working with voltages above 30 V ac rms, 42 V ac peak, or 60 V dc. These voltages pose a shock hazard.
- Use only the replacement fuse specified in the users manual.
- Use the proper terminals, function, and range for your measurements.
- Do not operate the tester around explosive gas, vapor, or dust.
- When using probes, keep your fingers behind the finger guards.
- When making electrical connections, connect the common test lead before connecting the live test lead; when disconnecting, disconnect the live test lead before disconnecting the common test lead.
- Replace the battery as soon as the low battery indicator (***) appears to avoid false readings that can lead to electric shock and injury.
- When servicing the tester, use only specified replacement parts.
- Do not use the tester in distribution systems with voltages higher than 550 V.
- When working on high energy systems, rubber gloves and flame-resistant face shield and clothing should be worn.

	Definition of Symbols Used					
	Fuse					
\triangle	Caution! Risk of Electric Shock.					
	Double Insulated (Class II) Equipment					
-	Earth Ground					
\triangle	Caution! Risk of Danger. Refer to Manual.					
C€	Conforms to relevant European standard.					
Do not use in distribution systems with voltages higher than 550 V.						
CAT III / CAT IV	CAT III Testers are designed to protect against transients in fixed- equipment installations at the distribution level; CAT IV Testers are designed to protect against transients from the primary supply level (overhead or underground utility service).					

Electrical Installation Tester

Introduction

The Fluke Model 1651B, Model 1652B, and Model 1653B are battery powered electrical installation testers. This manual applies to all three models. All figures show the Model 1653B.

The 165XB testers are designed to measure and test the following:

- Voltage and Frequency
- Insulation Resistance (EN61557-2)
- Continuity (EN61557-4)
- Loop/Line Resistance (EN61557-3)
- Residual Current Devices (RCD) Tripping Time (EN61557-6)
- RCD Tripping Current (EN61557-6)
- Earth Resistance (EN61557-5)
- Phase Sequence (EN61557-7)

How to Contact Fluke

To contact Fluke, call one of the following telephone numbers:

- Technical Support USA: 1-800-44-FLUKE (1-800-443-5853)
- Calibration/Repair USA: 1-888-99-FLUKE (1-888-993-5853)
- United Kingdom: +44 1603 256600
- Germany, Austria, Switzerland: +49-69-222-220-204
- Canada: 1-800-36-FLUKE (1-800-363-5853)
- Europe: +31 402-675-200
- Japan: +81-3-3434-0181
- Singapore: +65-738-5655
- Anywhere in the world: +1-425-446-5500

Or, visit Fluke's website at www.fluke.com.

To register your product, visit http://register.fluke.com.

To view, print, or download the latest manual supplement, visit http://us.fluke.com/usen/support/manuals.

Unpacking the Tester

The tester comes with the items listed in Table 1. If the tester is damaged or an item is missing, contact the place of purchase immediately.

Table 1. Standard Accessories

Description	1651B EU	1652B EU	1653B EU	1651B UK	1652B UK	1653B UK	Part Number
165X-8008 Probe, Multifunctional	√	$\sqrt{}$	\checkmark		\checkmark	\checkmark	2000757
Country Specific Mains Test Cord	√	$\sqrt{}$			$\sqrt{}$		See Table 2
TL-L1, Test Lead, Red		√	√				2044945
TL-L2, Test Lead Green	√	$\sqrt{}$	$\sqrt{}$				2044950
TL-L3, Test Lead Blue	√	√	√				2044961
Probe, Test, Banana Jack, 4 mm Tip, Red		~	~				2099044
Probe, Test, Banana Jack, 4 mm Tip, Green	√	$\sqrt{}$	$\sqrt{}$				2065297
Probe, Test, Banana Jack, 4 mm Tip, Blue	V	V	V				2068904
102-406-003, Probe cap,GS-38 Red		√	√				1942029
102-406-002, Probe cap,GS-38 Green	V	√	√				2065304
102-406-004, Probe cap,GS-38 Blue	V	√	√				2068919
AC285-5001,175-276-013 AC285 Large alligator clip, Red		√	V				2041727
AC285-5001-02,175-276-012 AC285 Large alligator clip, Green	V	V	V				2068133
AC285-5001-03,175-276-0114 AC285 Large alligator clip, Blue	V	V	V				2068265

Table 1. Standard Accessories (cont.)

Description	1651B EU	1652B EU	1653B EU	1651B UK	1652B UK	1653B UK	Part Number
Test lead set, 600 V, Fused Probe with alligator clips and prods, set of spare GS38 tips - Red, Blue, Green (Replacement fuse is an F 10 A 600 V, 50 kA, 6.3 x 32 mm)				V	√	√	2491989
CD ROM, Users Manual		√	$\sqrt{}$	√	$\sqrt{}$	$\sqrt{}$	3209538
Quick Reference Guide		√	√	√	$\sqrt{}$	√	3278157
Case, Tool Box, Yellow			$\sqrt{}$			$\sqrt{}$	1664213
Hard Case Insert, Foam, Polyurethane		V	1	V	V	V	2061011
Carrying Strap, Padded		√	$\sqrt{}$	√	√	√	2045406
Fluke-1653-2014, IR Adapter			$\sqrt{}$			\checkmark	2043365
Fluke Zero Adapter		\checkmark	$\sqrt{}$	\checkmark	$\sqrt{}$	\checkmark	3301338

Table 2. Country Specific Mains Cords

Mains Cord	Cord Type	Part Number
British	BS1363	2061367
Schuko	CEE 7/7	2061332
Denmark	AFSNIT 107-2-DI	2061371
Australia/New Zealand	AS 3112	2061380
Switzerland	SEV 1011	2061359
Italy	CEI 23-16/VII	2061344

Operating the Tester Using the Rotary Switch

Use the rotary switch (Figure 1 and Table 3) to select the type of test you want to perform.




Figure 1. Rotary Switch

apx013f.eps

Table 3. Rotary Switch

Number	Symbol	Measurement Function
1)	V	Volts.
2	R _{ISO}	Insulation resistance.
3	R _{LO}	Continuity.
4	Z _I NOTRIP	Loop impedance — No trip mode.
(5)	Z₁Ž← ≜TRIP	Loop impedance — Hi current trip mode.
6	ΔΤ	RCD tripping time.
7	$I_{\Delta N}$	RCD tripping level.
8	R _E	Earth resistance.
9	Q	Phase rotation.
(10)	N/A	Rotary switch.

Understanding the Pushbuttons

Use the pushbuttons (Figure 2 and Table 4) to control operation of the tester, select test results for viewing, and scroll through selected test results.




Figure 2. Pushbuttons

apx012f.eps

Table 4. Pushbuttons

No.	Button	Description			
11)	ZERO	Zero test lead resistance offset.			
12	(F1)	 Loop input select (L-N, L-PE). Voltage input select (L-N, L-PE, N-PE). RCD current rating (10, 30, 100, 300, 500, 1000 mA or VAR). Memory SELECT. 			
13	Enters Memory mode. Activates memory soft key selections (F1, F2, F3, or				
14)	F2	 RCD Current multiplier (x1/2, x1, x5, AUTO). Memory STORE. 			

Table 4. Pushbuttons (cont.)

No.	Button	Description			
15	•	 Scroll memory locations. Set memory location codes. Scroll Auto test results. Adjust current for VAR function. Display results if noise is present. 			
16	(F3)	 RCD type: AC (standard), S, or A (pulsed DC). Memory RECALL. Battery test. Loop R_E / I_K 			
17	 RCD test polarity (0, 180 degrees). Insulation test voltage (50, 100, 250, 500, or 1000 V). Memory CLEAR. 				
18		Turns the tester on and off. The tester will also shut off automatically is there is no activity for 10 minutes.			
19		Turns the backlight on and off.			
20	TEST	Starts the selected test. The key is surrounded by a "touch pad". The touch pad measures the potential between the operator and the tester's PE terminal. If you exceed a 100 V threshold, the symbol above the touch pad is illuminated.			

Understanding the Display

Figure 3 and Table 5 describe the display features.




Figure 3. Display Features

Table 5. Display Features

No.	Annunciator	Meaning
(21)	select store recall clear	Displays the selected Memory mode. Memory modes are: Select (Fi), Store (Fi), Recall (Fi), or Clear (Fi).
(22)	300500 Var ♣ 1000 mA L-NL-PEN-PE x1/2x1x5 AUTO I _K R _E 180° 1000 volts	Configuration options. Settings you can make within the measurement functions. For example, in the RCD Tripping Time function (ΔT) you can press (2) to multiply the test current by x1/2, x1, x5 or AUTO and you can press (3) to select the type of RCD you are testing.

apx020f.eps

Table 5. Display Features (cont.)

No.	Annunciator		Meaning
23)	0 0	Arrows above or below the terminal indicator symbol indicate reversed polarity. Check the connection or check the wiring to correct.	
(24)	0	Terminal indicator symbol. A terminal indicator symbol with a dot (o) in the center indicates the terminal is used for the selected function. The terminals are: • L (Line) • PE (Protective Earth) • N (Neutral)	
(25)	R _{LO} R _E R _{ISO} AT IA A	setting. T primary o	c the selected rotary switch The measurement value in the display also corresponds to the etting. Rotary switch settings are: Volts Insulation Continuity Loop no trip Loop hi current trip RCD trip time RCD trip current Earth
		Q	Phase Rotation
26)	RCD√	Indicates that the measured trip current (trip current test) or the measured trip time (trip time test) is according to the appropriate RCD standard and the fault voltage is below the selected limit. For more information, see Maximum Trip Time Table on page 46.	

Table 5. Display Features (cont.)

No.	Annunciator	Meaning
27)	U _L =	Indicates the preset fault voltage limit. The default setting is 50 V. Some locations require the fault voltage be set to 25 V, as specified by local electrical codes.
		Press (4) when you turn on the tester to toggle the fault voltage between 25 V and 50 V. The value you set will appear on the display and will be saved when you turn the tester off.
28)	> B B B B MS VAC MA M M M M M	Primary display and measurement units.
29	□ a □ □ □ b □ □ □ c □ □ □	Memory locations. See "Storing and Recalling Measurements" on page 32 for detailed information on using memory locations.
30)	-	Low battery icon. See "Testing and Replacing the Batteries" on page 35 for additional information on batteries and power management.
(31)	recall	Appears when you press the Recall button and you are looking at stored data.
32)	memory	Appears when you press the Memory button.
33	TEST	Appears when you press the Test button. Disappears when the test is completed.
34)	•	Appears when the instrument is overheated. The Loop test and RCD functions are inhibited when the instrument is overheated.

Table 5. Display Features (cont.)

No.	Annunciator	Meaning
35)	Δ	Appears when an error occurs. Testing is disabled. See "Error Codes" on page 13 for a listing and explanation of possible error codes.
36		Appears when the instrument is uploading data using Fluke PC software.
37)	U _N U _E	Name of the secondary measurement function.
	PSCI ^F PEFCI _K R _E	U _N Test voltage for insulation test. U _F Fault voltage. Measures neutral to earth. PSC
		Prospective Short Circuit. Calculated from measured voltage and impedance when reading line to neutral. PEFC
		Prospective Earth Fault Current. Calculated from voltage and loop impedance which is measured line to protective earth.
		I _K In combination with the PSC or PEFC symbol, indicates a short circuit current. R _E Earth resistance.

Table 5. Display Features (cont.)

No.	Annunciator	Meaning
(38)	>88.8.8 VDC VAC VAC KAN Hz	Secondary display and measurement units. Some tests will return more than one result or return a computed value based on the test result. This will occur with: • Volts • Secondary display shows line frequency. • Insulation tests • Secondary display shows actual test voltage. • Loop/line impedance • Secondary display shows PEFC (Prospective Earth Fault Current) or RE PSC (Prospective Short Circuit Current). • RCD switching time • Secondary display shows UF fault
		voltage. • RCD tripping current • Secondary display shows U _F fault voltage.
(39)	battery test	Appears when you are testing the batteries. For more information see "Testing and Replacing the Batteries" on page 35.
40	ZERO Ø	Appears when you press the button to zero the leads. After the zeroing operation, the icon stays illuminated indicating that zeroing has been performed. Only used when performing continuity or loop testing.
(41)	4	Potential danger. Appears when measuring or sourcing high voltages.

Input Terminals

Figure 4 shows the 165XB input terminals.




Figure 4. Input Terminals

Using the IR Port (Model 1653B Only)

The Model 1653B tester has an IR (infrared) port, see Figure 22, which allows you to connect the tester to a computer and upload test data using a Fluke PC software product. This automates your troubleshooting or recording process, reduces the possibility of manual error and allows you to collect, organize, and display test data in a format that meets your needs. See "Uploading Test Results" on page 34 for additional information on using the IR port.

Error Codes

Various error conditions are detected by the tester and are indicated with the \triangle icon, "Err", and an error number on the primary display. These error conditions disable testing and, if necessary, stop a running test.

Table 6. Error Codes

Error Condition	Code	Solution
Self-Test Fails	1	Return the tester to a Fluke Service Center.
Over-Temp	2	Wait while the tester cools down.
Fault Voltage	4	Check the installation, in particular, the voltage between N and PE.
Excessive Noise	5	Switch off all appliances (Loop, RCD measurements) and move the earth stakes (earth measurement).
Excessive Probe Resistance	6	Put the stakes deeper into the soil. Tamp down the soil directly around the stakes. Pour water around the stakes but not at the earth ground under test.




Figure 5. Error Display

apx032f.eps

Power-On Options

To select a power-on option, press ① and the function key simultaneously and then release the ① button. Power-on options are retained when the tester is turned OFF.

Table 7. Power-On Options

Keys	Power-On Options	
① F2	Loop/Line Impedance I_K limit. Toggles the I_K limit between 10 kA and 50 kA. The default is 10 kA.	
	Line and Neutral Swap mode. Two modes of operation are available. You can configure the tester to operate in L-n mode or L-n n-L mode, see figure 6.	
(ii) (ii)	• In L-n mode, the L and N phase conductors must NEVER be reversed. This is a requirement in some regions including the UK. The ©© icon appears on the display indicating that the system L and N conductors are swapped and testing is inhibited. Investigate and rectify the cause of this system fault before proceeding. L-n mode also changes the RCD x1/2 trip time duration to 2 seconds as required in the UK.	
	In L-n n-L mode, the unit allows the L and N phase conductors to be swapped and testing will continue.	
	Note	
	In locations where polarized plugs and outlets are used, a swapped lead icon (๑´๑) may indicate that the outlet was wired incorrectly. Correct this problem before proceeding with any testing.	
① F4	Fault voltage limit. Toggles the fault voltage between 25 V and 50 V. The default is 50 V.	
(I) (MEMORY)	View the tester serial number. Primary display shows the initial four digits and the secondary display shows the next four digits.	
③ ③	Continuity beeper toggle. Toggles the continuity beeper on and off. The default is on.	




Figure 6. Lead Swapping Modes

apx026f.eps

Making Measurements

Measuring Volts and Frequency




Figure 7. Volts Display/Switch and Terminal Settings

To measure voltage and frequency:

1. Turn the rotary switch to the V position.

- Use all (red, blue, and green) terminals for this test. You can use test leads or mains cord when measuring AC voltage.
 - The primary (upper) display shows the AC voltage. The tester reads AC voltage to 500 V. Press (a) to toggle the voltage reading between L-PE, L-N, and N-PE.
 - The secondary (lower) display shows mains frequency.

Measuring Insulation Resistance




Figure 8. Insulation Resistance Display/Switch and Terminal Settings

∧ ∧ Warning

Measurements should only be performed on de-energized circuits.

To measure insulation resistance:

- Turn the rotary switch to the R_{ISO} position.
- 2. Use the L and PE (red and green) terminals for this test.
- 3. Use the [♠] to select the test voltage. Most insulation testing is performed at 500 V, but observe local test requirements.
- 4. Press and hold first until the reading settles and the tester beeps.

Note

Testing is inhibited if voltage is detected in the line.

- The primary (upper) display shows the insulation resistance.
- The secondary (lower) display shows the actual test voltage.

Note

For normal insulation with high resistance, the actual test voltage (U_N) should always be equal to or higher than the programmed voltage. If insulation resistance is bad, the test voltage is automatically reduced to limit the test current to safe ranges.

Measuring Continuity




Figure 9. Continuity Zero Display/Switch and Terminal Settings

A continuity test is used to verify the integrity of connections by making a high resolution resistance measurement. This is especially important for checking Protective Earth connections.

Note

In countries where electrical circuits are laid out in a ring, it is recommended that you make an end-to-end check of the ring at the electrical panel.

▲ Marning

- Measurements should only be performed on de-energized circuits.
- Measurements may be adversely affected by impedances or parallel circuits or transient currents.

To measure continuity:

- 1. Turn the rotary switch to the R_{I O} position.
- 2. Use the L and PE (red and green) terminals for this test.
- Before making a continuity test, use the Zero adapter to zero the test leads.
 Press and hold (ZERO) until the ZERO annunciator appears. The tester measures probe resistance, stores the reading in memory, and subtracts it


from readings. The resistance value is saved even when power is turned off so you don't need to repeat the operation every time you use the instrument.

Note

Be sure the batteries are in good charge condition before you zero the test leads.

4. Press and hold $\stackrel{\frown}{=}$ until the reading settles. If the continuity beeper is enabled, the tester beeps continuously for measured values less than 2 Ω and there is no stable reading beep for measured values greater than 2 Ω . If a circuit is live, the test is inhibited and the AC voltage appears in the secondary (lower) display.

Measuring Loop/Line Impedance



apx006f.eps

Figure 10. Loop/Line Impedance/Switch and Terminal Settings

Loop Impedance (Line to Protective Earth L-PE)

Loop impedance is source impedance measured between Line (L) and Protective Earth (PE). You can also ascertain the Prospective Earth Fault Current (PEFC) that is the current that could potentially flow if the phase conductor is shorted to the protective earth conductor. The tester calculates the PEFC by dividing the measured mains voltage by the loop impedance. The loop impedance function applies a test current that flows to earth. If RCDs are present in the circuit, they may trip. To avoid tripping, always use the Z_I No Trip function on the rotary switch. The no trip test applies a special test that prevents RCDs in the system from tripping. If you are certain no RCDs are in the circuit, you can use the Z_I Hi Current function for a faster test.

Note

If the L and N terminals are reversed, the tester will auto-swap them internally and continue testing. If the tester is configured for UK operation, testing will halt. This condition is indicated by arrows above or below the terminal indicator symbol (© © •).

To measure loop impedance no trip mode:

∧ M Warning

To prevent tripping RCDs in the circuit:

- Always use the Z_I NOTRIP position for loop measurements.
- · Preload conditions can cause the RCD to trip.
- An RCD with a nominal fault current of 10 mA will trip.

Note

To do a Loop impedance test in a circuit with a 10 mA RCD, we recommend a trip time RCD test. Use a nominal test current of 10 mA and the factor x % for this test.

If the fault voltage is below 25 V or 50 V, dependent on the local requirement, the loop is good. To calculate the loop impedance, divide the fault voltage by 10 mA (Loop impedance = fault voltage x 100).

- 1. Turn the rotary switch to the Z₁ NOTRIP position.
- Connect all three leads to the L, PE, and N (red, green, and blue) terminals of the tester.
- 3. Press \odot to select L-PE. The display shows the Z_L and \longrightarrow indicator.
- 4. Before you do a loop impedance test, use the zero adapter to zero the test leads or the mains cord. Press and hold reprosent the tester measures are seconds until the ZERO annunciator appears. The tester measures the lead resistance, stores the reading in memory, and subtracts it from readings. The resistance value is saved even when the power is turned off so it is unnecessary to repeat the operation each time you use the tester with the same test leads or mains cord.

Note

Be sure the batteries are in good charge condition before you zero the test leads

Connect all three leads to the L, PE, and N of the system under test or plug the mains cord into the socket under test.




Figure 11. Display After Zeroing

apx033f.eps

- Press and release . Wait for the test to complete.
 The primary (upper) display shows the loop impedance.
- To read the Prospective Earth Fault Current, press the (3) key and select I_K. The Prospective Earth Fault Current appears in amps or kilo amps in the secondary (lower) display.
- 8. If the mains is too noisy, Err 5 will be displayed. (The measured value accuracy is degraded by the noise.) Press the down arrow \(\hat{S} \) to display the measured value. Press the up arrow \(\hat{S} \) to return to the Err 5 display.

This test will take several seconds to complete. If the mains is disconnected while the test is active, the test automatically terminates.

Note

Errors may occur due to preloading the circuit under test.

To measure loop impedance—Hi current trip mode:

If no RCDs are present in the system under test, you can use the high current Line Earth (L-PE) loop impedance test.

- 1. Turn the rotary switch to the $\frac{Z_1 V_{\bullet}}{\Delta_{TRIP}}$ position.
- Connect all three leads to the L, PE, and N (red, green, and blue) terminals of the tester.
- Press
 f) to select L-PE. The

 — appears to indicate that hi current trip mode is selected.
- 4. Repeat Steps 4 through 8 from the preceding test.

△ M Warning

The symbol — on the LCD indicates the high current loop mode - any RCDs in the system will trip - ensure there are no RCDs present.

Earth Resistance Testing by Loop Method

You can also use the tester to measure the earth resistance component of the total loop resistance. Check your local regulations to determine if this method is acceptable in your area. You can use three leads or the mains cord to perform this test. Use the connection shown in Figure 12 when making a 3-wire connection for earth resistance loop test. Zero the test leads (see sequence for Loop Impedance measurement).




Figure 12. 3-Wire Connection for Earth Resistance Loop Test

To measure earth resistance using the loop test no trip mode:

- 1. Turn the rotary switch to the **Z**₁ NOTRIP position.
- 2. Press (f) to select L-PE.
- 3. Press $^{\text{F3}}$ to select R_E (resistance).
- 4. Press and release (TEST). Wait for the test to complete.
 - The primary (upper) display shows the loop impedance.
 - The secondary (lower) display shows the earth resistance.

Line Impedance

Line impedance is source impedance measured between Line conductors or Line and Neutral. This function allows the following tests:

- Line to Neutral loop impedance.
- Line to Line impedance in 3-phase systems.

- L-PE loop measurement. This is a way of making a high current, 2-wire loop measurement. It cannot be used on circuits protected by RCDs because it will cause them to trip.
- Prospective Short Circuit Current (PSC). PSC is the current that can
 potentially flow if the phase conductor is shorted to the neutral conductor or
 another phase conductor. The tester calculates the PSC current by dividing
 the measured mains voltage by the line impedance.




Figure 13. Line Impedance Display

apx034f.eps

To measure line impedance:

- Turn the rotary switch to the Z_{\(\Delta\text{TRIP}\)} position. The LCD indicates that the high current loop mode is selected by displaying the ∠ symbol.
- 2. Connect the red lead to the L (red) and the blue lead to the N (blue) terminals of the tester.
- 3. Press (F1) to select L-N.
- 4. Use the zero adapter to zero the test leads or the mains cord.
- Press and hold (ZERO) for more than two seconds until the ZERO annunciator appears.

The tester measures the lead resistance, stores the reading in memory, and subtracts it from readings. The resistance value is saved even when the power is turned off so it is unnecessary to repeat the operation each time you use the tester with the same test leads or mains cord.

Note

Be sure the batteries are in good charge condition before you zero the test leads.

^ Marning

At this step, be careful not to select L-PE because a high current loop test will take place. Any RCDs in the system will trip if you proceed.

Note

Connect the leads in a single-phase test to the system live and neutral. To measure line-to-line impedance in a 3-phase system, connect the leads to 2 phases.

- 6. Press and release (1837). Wait for the test to complete.
- The primary (upper) display shows the line impedance.
- The secondary (lower) display shows the Prospective Short Circuit Current (PSC).
- 7. If the mains is too noisy, Err 5 will be displayed. (The measured value accuracy is degraded by the noise). Press the down arrow \mathsection to display the measured value. Press the up arrow \mathsection to return to the Err 5 display.

Use the connection shown in Figure 14 when measuring in a 3-phase 500 V system.




Figure 14. Measuring in a 3-Phase System

apx025f.eps

Measuring RCD Tripping Time




Figure 15. RCD Tripping Time Display/Switch and Terminal Settings

In this test, a calibrated fault current is induced into the circuit, causing the RCD to trip. The meter measures and displays the time required for the RCD to trip. You can perform this test with test leads or using the mains cord. The test is performed with a live circuit.

You can also use the tester to perform the RCD tripping time test in Auto mode, which makes it easier for one person to perform the test. If the RCD has a special nominal current setting other than the standard options, 10, 30, 100, 300, 500 1000 mA, you can use a custom setting with the VAR mode.

Note

When measuring trip time for any type of RCD, the tester first does a pretest to determine if the actual test will cause a fault voltage exceeding the limit (25 or 50 V).

To avoid having an inaccurate trip time for S type (time delay) RCDs, a 30 second delay is activated between the pretest and the actual test. This RCD type needs a delay because it contains RC circuits that are required to settle before applying the full test.

▲ Marning

- Test the connection between the N-conductor and earth before starting the test. A voltage between the N-conductor and earth may influence the test.
- Leakage currents in the circuit following the residual current protection device may influence measurements.
- The displayed fault voltage relates to the rated residual current of the RCD.

- Potential fields of other earthing installations may influence the measurement.
- Equipment (motors, capacitors) connected downstream of the RCD may cause considerable extension of the tripping time.

Note

If the L and N terminals are reversed, the tester will auto-swap them internally and continue testing. If the tester is configured for UK operation, testing will halt and you will need to determine why the L and N are swapped. This condition is indicated by arrows above or below the terminal indicator symbol (© © •).

Type A RCDs do not have the 1000mA option available.

To measure RCD tripping time:

- 1. Turn the rotary switch to the ΔT position.
- Press (a) to select the RCD current rating (10, 30, 100, 300, 500, or 1000 mA).
- 3. Press (2) to select a test current multiplier (x ½, x 1, x 5, or Auto). Normally you will use x 1 for this test.

Note

Model 1651B does not allow the Auto Selection.

- 4. Press (F3) to select the RCD test-current waveform:
 - AC current to test type AC (standard AC RCD) and type A (pulse-DC sensitive RCD*)
 - Pulse current to test type A (pulse-DC sensitive RCD*)

 - S Delayed response to S-type A (time delayed pulse-DC sensitive RCD*)
 - * Models 1652B and 1653B only
- 5. Press (a) to select the test current phase, 0° or 180°. RCDs should be tested with both phase settings, as their response time can vary significantly depending on the phase.
- 6. Press and release (rest). Wait for the test to complete.
 - The primary (upper) display shows the trip time.
 - The secondary (lower) display shows the fault voltage (N to PE) related to the rated residual current.

 If the trip time is according to the appropriate standard of the RCD, the RCD ✓ indicator displays. For more information, see Maximum Trip Time Table on page 46.

To measure RCD tripping time for a custom RCD setting – VAR mode:

- 1. Turn the rotary switch to the ΔT position.
- 2. Press (a) to select the VAR current rating. The current custom setting shows on the primary display. Use the (3) arrow keys to adjust the value.
- 3. Press (2) to select a test current multiplier. Normally you will use x 1/2 or x 1 for this test.
- Repeat steps 4 through 6 listed in the preceding RCD tripping time procedure.
- 5. To view the nominal setting used for the test, depress the \Im arrow key.

Note

The maximum setting for type A RCDs is 700 mA.

To measure RCD tripping time using Auto mode:

- 1. Plug the tester into the outlet.
- 2. Turn the rotary switch to the ΔT position.
- 3. Press (f) to select the RCD current rating (10, 30, or 100 mA).
- 4. Press (F2) to select Auto mode.
- 5. Press (F3) to select the RCD test-current waveform.
- 6. Press and release (TEST).


The tester supplies $\frac{1}{2}x$ the rated RCD current for 310 or 510 ms (2 seconds in the UK). If the RCD trips, the test terminates. If the RCD does not trip, the tester reverses phase and repeats the test. The test terminates if the RCD Trips.

If the RCD does not trip, the tester restores the initial phase setting and supplies 1x the rated RCD current. The RCD should trip and the test results appear in the primary display.

- 7. Reset the RCD.
- 8. The tester reverses phases and repeats the 1x test. The RCD should trip and the test results appear in the primary display.
- Reset the RCD.
- The tester restores the initial phase setting and supplies 5x the rated RCD current for up to 50 ms. The RCD should trip and the test results appear in the primary display.

- 11. Reset the RCD.
- 12. The tester reverses phase and repeats the 5x test. The RCD should trip and the test results appear in the primary display.
- 13. Reset the RCD.
 - You can use the $\ensuremath{\lozenge}$ arrow keys to review test results. The first result shown is the last measurement taken, the 5x current test. Press the down arrow key $\ensuremath{\lozenge}$ to move backward to the first test at $\ensuremath{\checkmark}$ x the rated current.
 - If the trip time is according to the appropriate standard of the RCD, the RCD ✓ indicator displays. For more information, see Maximum Trip Time Table on page 46.
- 14. Test results are in temporary memory. If you want to store the test results, press want proceed as described in "Storing and Recalling Measurements" on page 32 of this manual. Measurement storage and recall is available only on Model 1653B.

Measuring RCD Tripping Current (Models 1652B and 1653B Only)



apx009f.eps

Figure 16. RCD Tripping Current/Switch and Terminal Settings

This test measures the RCD tripping current by applying a test current and then gradually increasing the current until the RCD trips. You can use the test leads or mains cord for this test. A 3-wire connection is required.

△△ Warning

- Test the connection between the N-conductor and earth before starting the test. A voltage between the N-conductor and earth may influence the test.
- Leakage currents in the circuit following the residual current protection device may influence measurements.

- The displayed fault voltage relates to the rated residual current of the RCD.
- Potential fields of other earthing installations may influence the measurement.

Note

If the L and N terminals are reversed, the tester will auto-swap them internally and continue testing. If the tester is configured for UK operation, testing will halt and you will need to determine why the L and N are swapped. This condition is indicated by arrows above or below the terminal indicator symbol (()).

Type A RCDs do not have the 1000 mA option available.

To measure RCD tripping current:

- 1. Turn the rotary switch to the $I_{\Lambda N}$ position.
- 2. Press (a) to select the RCD current rating (10, 30, 100, 300, or 500 mA). If the RCD has a special nominal current setting other than the standard options, 10, 30, 100, 300, 500 1000 mA, you can use a custom setting with the VAR mode.
- 3. Press (F3) to select the RCD test-current waveform:
 - — AC current to test type AC (standard AC RCD) and type A
 (pulse-DC sensitive RCD*)
 - – Pulse current to test type A (pulse-DC sensitive RCD*)

 - S Delayed response to S-type A (time delayed pulse-DC sensitive RCD*)
 - * Models 1652B and 1653B only
- 4. Press (a) to select the test current phase, 0° or 180°. RCDs should be tested with both phase settings, as their response time can vary significantly depending on the phase.
- 5. Press and release . Wait for the test to complete.
 - The primary (upper) display shows the RCD trip current.
 - If the trip current is according to the appropriate standard of the RCD, the RCD ✓ indicator displays. For more information, see Maximum Trip Time Table on page 46.

To measure RCD tripping current for a custom RCD setting - VAR mode:

- 1. Turn the rotary switch to the $I_{\Lambda N}$ position.
- 2. Press (e) to select the VAR current rating. The current custom setting shows on the primary display. Use the (g) arrow keys to adjust the value.

- 3. Repeat steps 3 through 5 listed in the preceding RCD tripping current procedure.
- 4. To view the nominal test setting, depress the \(\hat{3} \) arrow key.

Note

The maximum setting for RCDs is 700 mA.

RCD Testing in IT Systems

RCD testing at locations with IT systems requires a special test procedure because the Protective Earth connection is grounded locally and is not tied directly to the power system.

The test is conducted at the electrical panel using probes. Use the connection shown in Figure 17 when performing RCD testing on IT electrical systems.




Figure 17. Connection for RCD Testing on IT Electrical Systems

The test current flows through the upper side of the RCD, into the L terminal, and returns though the PE terminal.

Measuring Earth Resistance (Model 1653B Only)




Figure 18. Earth Resistance Display/Switch and Terminal Settings

The earth resistance test is a 3-wire test consisting of two test stakes and the earth electrode under test. This test requires an accessory stake kit. Connect as shown in Figure 19.

- Best accuracy is achieved with the middle stake at 62 % of the distance to the far stake. The stakes should be in a straight line and wires separated to avoid mutual coupling.
- The earth electrode under test should be disconnected from the electrical system when conducting the test. Earth resistance testing should not be performed on a live system.




Figure 19. Earth Resistance Test Connection

apx014f.eps

To measure earth resistance:

- 1. Turn the rotary switch to the $\mathbf{R}_{\mathbf{E}}$ position.
- 2. Press and release (ssr). Wait for the test to complete.

- The primary (upper) display shows the earth resistance reading.
- Voltage detected between the test rods will be displayed in the secondary display. If greater than 10 V, the test is inhibited.
- If the measurement is too noisy, Err 5 will be displayed. (The
 measured value accuracy is degraded by the noise). Press the down
 arrow ((3)) to display the measured value. Press the up arrow ((3)) to
 return to the Err 5 display.
- If the probe resistance is too high, Err 6 is displayed. Probe resistance
 may be reduced by driving the test stakes further into the earth or
 wetting the earth around the test stakes.

Testing Phase Sequence (Model 1653B Only)




Figure 20. Phase Sequence Display/Switch and Terminal Settings

Use the connection shown in Figure 21 for a phase sequence test connection.




Figure 21. Phase Sequence Test Connection

apx022f.eps

To perform a phase sequence test:

1. Turn the rotary switch to the 🥎 position.

- 2. The primary (upper) display shows:
 - 123 for correct phase sequence.
 - 321 for reversed phase sequence.
 - Dashes (---) instead of numbers if insufficient voltage is sensed.

Storing and Recalling Measurements (Model 1653B Only)

Using Memory Mode

You can store up to 444 measurements on the tester. The information stored for each measurement consists of the test function and all user selectable test conditions.

Data for each measurement is assigned a data set number, data subset number, and a data id number. Memory location fields are used as described below.

Field	Description
∟ а	Use the data set field (a) to indicate a location such as a room or electrical panel number.
└─_ b <i>─</i> ─	Use the data subset field (b) for circuit number.
c	The data id number field (c) is the measurement number. The measurement number automatically increments. The measurement number can also be set to a previously used value to overwrite an existing measurement.

To enter Memory mode:

- 1. Press the work to enter Memory mode. The display changes to a memory mode display. In Memory mode, the memory icon appears on the display. The primary numeric display will be active with the left two digits (a) indicating the data set number (1-99) and the right two digits (b) indicating the data subset number. The decimal point separating these two values will be active. The secondary numeric display (c) will be active indicating the data id number (1-444). The memory locations (a, b, or c) will flash, indicating that you can change the number using the arrow keys ...
- 2. To enable the data subset number to be changed, press (a). The data subset number will now be flashing. To enable the data sub number to be changed, press (b) again. The data set number will now be flashing. Press (b) again to change the data id number.

3. Press the down arrow key (③) to decrement the enabled number or press the up arrow key (⑤) to increment the enabled number. For storing data, the number can be set to any value, overwriting existing data is allowed. For recalling data, the number can only be set to used values.

Note

If you press the up or down arrow key (\Im) once, the number increments or decrements by one. If you press and hold the up or down arrow, the numbers increment or decrement quickly by approximately 10 digits per second.

Storing a Measurement

To store a measurement:

- 1. Press (MEMORY) to enter Memory mode.
- 2. Press (F1) and use the arrow keys ((3)) to set the data identity.
- 3. Press (F2) to save the data.
 - If memory is full, FULL will appear on the primary display. Press (F) to choose another data identity, press (E) to exit Memory mode.
 - If the memory is not full, the data will be saved, the tester will automatically exit Memory mode and the display will revert back to the previous test mode.
 - If the data identity has been previously used, the display will show STO? Press ② again to store the data, press ③ to choose another data identity, press ④ to exit Memory mode.

Recalling a Measurement

To recall a measurement:

- 1. Press (MEMORY) to enter the Memory mode.
- 2. Press (F3) to enter the Recall mode.
- 3. Use 🗈 and the arrow keys (()) to set the data identity. If no data has been saved, all fields will be dashes.
- 4. Press (3) to recall the data. The tester display will revert to the Test mode used for the recalled test data, however, the memory icon still appears, indicating the tester is still in Memory mode.
- 5. Press (s) to toggle between the data id screen and the recalled data screen to check the recalled data id or to select more data to recall.
- 6. Press (MEMORY) to exit Memory mode at any time.

Clearing Memory

To clear all memory:

- 1. Press MEMORY to enter Memory mode.
- 2. Press (a). The primary display will show Clr? Press (b) again to clear all memory locations.
- 3. Press (MEMORY) to exit Memory mode.

Note

All memory locations are cleared when you clear memory. Single memory locations cannot be cleared, but they can be overwritten. See "Storing a Measurement" earlier in this manual.

Uploading Test Results (Model 1653B Only)




Figure 22. Attaching the IR Adapter

apx031f.eps

To upload test results:

- 1. Connect the IR serial cable to the serial port on the PC.
- Attach the IR adapter and the device to the tester as shown in Figure 22.
 Be sure to align the IR adapter to the IR port on the tester.

Note

The IR data port is disabled when test leads are plugged in. Disconnect test leads before attempting to upload test results.

- 3. Start the Fluke PC software program.
- 4. Press ① to turn on the tester.
- 5. Refer to the software documentation for complete instructions on how to set the date/time stamp and upload data from the tester.

Maintaining the Tester Cleaning

Periodically wipe the case with a damp cloth and mild detergent. Do not use abrasives or solvents.

Dirt or moisture in the terminals can affect readings.

To clean the terminals:

- 1. Turn the meter off and remove all test leads.
- 2. Shake out any dirt that may be in the terminals.
- 3. Soak a new swab with alcohol. Work the swab around each terminal.

Testing and Replacing the Batteries

Battery voltage is continuously monitored by the tester. If the voltage falls below 6.0 V (1.0 V/cell), the low battery icon appears on the display, indicating that there is minimal battery life left. The low battery icon continues to appear on the display until you replace the batteries.

M M Warning

To avoid false readings, which could lead to possible electric shock or personal injury, replace the batteries as soon as the battery icon () appears.

Be sure that the battery polarity is correct. A reversed battery can cause leakage.

Replace the batteries with six AA batteries. Alkaline batteries are supplied with the tester but you can also use 1.2 V NiCd or NiMH batteries. You can also check the battery charge so that you can replace them before they discharge.

▲ Marning

To avoid electrical shock or personal injury, remove the test leads and any input signals before replacing the battery. To prevent damage or injury, install ONLY specified replacement fuses with the amperage, voltage, and speed ratings shown in the General Specifications section of this manual.

To test the batteries:

- Turn the rotary switch to the V position.
- 2. Press (s) to initiate the battery test. The Voltage function display clears and is replaced by the measured battery voltage in the secondary display for 2 seconds, the Voltage function display then returns.

To replace the batteries (Refer to Figure 23):

1. Press ① to turn the tester off.

- Remove the test leads from the terminals.
- 3. Remove the battery door by using a standard-blade screwdriver to turn the battery door screws (3) one-quarter turn counterclockwise.
- 4. Press the release latch and slide the battery holder out of the tester.
- 5. Replace the batteries and the battery door.

Note

All stored data will be lost if the batteries are not replaced within approximately one minute (Model 1653B only).

6. Secure the door by turning the screws one-quarter turn clockwise.




Figure 23. Replacing the Batteries

apx028f.eps

Testing the Fuse

A fuse test is performed each time you turn on the tester. If leads are plugged into the L and PE terminals, the fuse test is skipped. If a blown fuse is detected, testing is disabled, FUSE appears on the primary display, and the tester issues a warning beep.

You can also perform a manual check of the fuse.

To manually check the fuse:

- 1. Turn the rotary switch to either R_{ISO} or R_{LO} switch setting.
- 2. Short the leads and press and hold s.
- 3. If the fuse is bad, FUSE will appear on the display to indicate the tester is damaged and needs repair. Contact Fluke Service for repair (see *Contacting Fluke*).

Specifications

Features by Model

Measurement Function	1651B	1652B	1653B			
Voltage & Frequency	√	√	V			
Wiring polarity checker	√	√	V			
Insulation Resistance	√	√	√			
Continuity & Resistance	√	√	V			
Loop & Line Resistance	√	√	√			
Prospective Earth Fault Current (PEFC/I _K) Prospective Short-Circuit current (PSC/I _K)	√	√	√			
RCD switching time	√	√	$\sqrt{}$			
RCD tripping level		√	√			
		ramp test	ramp test			
RCD variable current	√	√	$\sqrt{}$			
Automatic RCD test sequence		\checkmark	$\sqrt{}$			
Test pulse current sensitive RCDs (Type A)		√	\checkmark			
Earth Resistance			\checkmark			
Phase Sequence Indicator			\checkmark			
Other Featur	es					
Self-test	$\sqrt{}$	√	\checkmark			
Illuminated Display	$\sqrt{}$	$\sqrt{}$	\checkmark			
Memory, Inter	face					
Memory			$\sqrt{}$			
Computer Interface			$\sqrt{}$			
Time and date (When used with FlukeView software)			\checkmark			
Software			$\sqrt{}$			
Included Accessories						
Hard case	V	√	$\sqrt{}$			
Remote control probe ^[1]	√	√	√			
Zero Adapter	V	√	$\sqrt{}$			
Note [1] Included with all 165XB versions except 1651B UK	Version.					

General Specifications

Specification	Characteristic
Size	10 cm (L) x 25 cm (W) x 12.5 cm (H)
Weight (with batteries)	1.5 kg
Battery size, quantity	Type AA, 6 ea.
Battery type	Alkaline supplied.
	Usable with 1.2 V NiCd or NiMH batteries (not supplied)
Battery life (typical)	200 hours idling
Fuse	T3.15 A, 500 V, 1.5 kA 6.3 x 32 mm (PN 2030852)
Operating Temperature	-10 °C to 40 °C
Storage Temperature	-10 °C to 60 °C indefinitely (to -40 °C for 100 hrs)
Relative Humidity	Noncondensing <10 °C
	95 % 10 to 30 °C; 75 % 30 to 40 °C
Operating Altitude	0 to 2000 meters
Shock, Vibration	Vibration to Class 3 per Mil-Prf-28800F
	1 meter drop test, six sides, oak floor
Sealing	IP 40
EMC	Complies with EN61326-1: 2006
Safety	Complies with EN61010-1 Ed 2.0 (2001-02), UL61010, ANSI/ISA -s82.02.01 2000 and CAN/CSA c22.2 No.1010 2nd edition
	Overvoltage Category: 500 V/CAT III
	300 V/CAT IV
	Measurement Category III is for measurements performed in the building installation. Examples are distribution panels, circuit breakers, wiring and cabling.
	Category IV equipment is designed to protect against transients from the primary supply level, such as an electrical meter or an overhead or underground utility service.
	Performance EN61557-1, EN61557-2, EN61557-3, EN61557-4, EN61557-5, EN61557-6, EN61557-7 Second edition. EN61557-10 First edition.
Maximum voltage between any terminal and earth ground	500 V
Surge Protection	6 kV peak per EN 61010-1 Ed. 2.0 (2001-02)

Electrical Measurement Specifications

The accuracy specification is defined as \pm (% reading +digit counts) at 23 °C \pm 5 °C, \leq 80 % RH. Between -10 °C and 18 °C and between 28 °C and 40 °C, accuracy specifications may degrade by 0,1 x (accuracy specification) per °C. The following tables can be used for the determination of maximum or minimum display values considering maximum instrument operating uncertainty per EN61557-1, 5.2.4.

Insulation Resistance (R_{ISO})

	50 V	1	00 V	2	50 V	50	00 V	10	000 V
Limit Value	Maximum Display Value								
1	1.12	1	1.12	1	1.3	1	1.3	1	1.3
2	2.22	2	2.22	2	2.4	2	2.4	2	2.4
3	3.32	3	3.32	3	3.5	3	3.5	3	3.5
4	4.42	4	4.42	4	4.6	4	4.6	4	4.6
5	5.52	5	5.52	5	5.7	5	5.7	5	5.7
6	6.62	6	6.62	6	6.8	6	6.8	6	6.8
7	7.72	7	7.72	7	7.9	7	7.9	7	7.9
8	8.82	8	8.82	8	9.0	8	9.0	8	9.0
9	9.92	9	9.92	9	10.1	9	10.1	9	10.1
10	11.02	10	11.02	10	11.2	10	11.2	10	11.2
20	22.02	20	22.02	20	22.2	20	22.2	20	22.2
30	33.02	30	33.2	30	33.2	30	33.2	30	33.2
40	44.02	40	44.2	40	44.2	40	44.2	40	44.2
50	55.02	50	55.2	50	55.2	50	55.2	50	55.2
		60	66.2	60	66.2	60	66.2	60	66.2
		70	77.2	70	77.2	70	77.2	70	77.2
		80	88.2	80	88.2	80	88.2	80	88.2
		90	99.2	90	99.2	90	99.2	90	99.2
		100	110.2	100	110.2	100	110.2	100	110.2
				200	220.2	200	220.2	200	220.2
						300	347	300	345
						400	462	400	460
						500	577	500	575
								600	690
								700	805
								800	920
								900	1035
								1000	1150

Continuity (R_{LO})

Limit Value	Maximum Display Value	Limit Value	Maximum Display Value
0.2	0.16	3	2.68
0.3	0.25	4	3.58
0.4	0.34	5	4.48
0.5	0.43	6	5.38
0.6	0.52	7	6.28
0.7	0.61	8	7.18
0.8	0.7	9	8.08
0.9	0.79	10	8.98
1	0.88	20	17.98
2	1.78	30	26.8

Loop Tests (Z_I)

	op Z _I Surrent		op Z _i Trip	Lo	oop Z _i	Loc	op R _E
Limit Value	Maximum Display Value	Limit Value	Maximum Display Value	Limit Value	Maximum Display Value	Limit Value	Maximum Display Value
0.20	0.14	•	-	3	2.53	3	2.72
0.30	0.23	•	-	4	3.38	4	3.62
0.40	0.32	0.40	0.28	5	4.23	5	4.52
0.50	0.41	0.50	0.37	6	5.08	6	5.42
0.60	0.50	0.60	0.45	7	5.93	7	6.32
0.70	0.59	0.70	0.54	8	6.78	8	7.22
0.80	0.68	0.80	0.62	9	7.63	9	8.12
0.90	0.77	0.90	0.71	10	8.48	10	9.02
1.00	0.86	1.00	0.79	20	16.98	20	18.02
1.10	0.95	1.10	0.88	30	25.3	30	27.2
1.20	1.04	1.20	0.96	40	33.8	40	36.2
1.30	1.13	1.30	1.05	50	42.3	50	45.2
1.40	1.22	1.40	1.13	60	50.8	60	54.2
1.50	1.31	1.50	1.22	70	59.3	70	63.2
1.60	1.40	1.60	1.30	80	67.8	80	72.2
1.70	1.49	1.70	1.39	90	76.3	90	81.2
1.80	1.58	1.80	1.47	100	84.8	100	90.2
1.90	1.67	1.90	1.56	200	169.8	200	180.2
2.00	1.76	2.00	1.64	300	253	300	272
-	-	-	-	400	338	400	362

-	-	-	-	500	423	500	452
-	-	-	-	600	508	600	542
-	-	-	-	700	593	700	632
-	-	-	-	800	678	800	722
-	-	-	-	900	763	900	812
-	-	-	-	1000	848	1000	902

RCD/FI Tests ($_{\Delta}T$, $I_{\Delta}N$)

RC	D/FI Time	RC	D/FI Current
Limit Value	Maximum Display Value	Limit Value	Maximum Display Value
20	18.1	0.5	0.43
30	27.1	0.6	0.52
40	36.1	0.7	0.61
50	45.1	0.8	0.7
60	54.1	0.9	0.79
70	63.1	1	0.88
80	72.1	2	1.78
90	81.1	3	2.68
100	90.1	4	3.58
200	180.1	5	4.48
300	271	6	5.38
400	361	7	6.28
500	451	8	7.18
600	541	9	8.08
700	631	10	8.98
800	721	20	17.98
900	811	30	26.8
1000	901	40	35.8
2000	1801	50	44.8
		60	53.8
		70	62.8
		80	71.8
		90	80.8
		100	89.8
		200	179.8
		300	268
		400	358
		500	448

Earth Tests (R_E)

Limit Value	Maximum Display Value	Limit Value	Maximum Display Value
10	8.8	200	179.8
20	17.8	300	268.0
30	26.8	400	358.0
40	35.8	500	448.0
50	44.8	600	538.0
60	53.8	700	628.0
70	62.8	800	718.0
80	71.8	900	808.0
90	80.8	1000	898.0
100	89.8	2000	1798.0

AC Voltage Measurement (V)

Range	Resolution	Accuracy 50 Hz – 60 Hz	Input Impedance	Overload Protection
500 V	0.1 V	0.8 % + 3	3.3 MΩ	660 V rms

Continuity Testing (R_{LO})

Range (Autoranging)	Resolution	Open Circuit Voltage	Accuracy
20 Ω	0.01 Ω	>4 V	±(1.5 % + 3 digits)
200 Ω	0.1 Ω	>4 V	±(1.5 % + 3 digits)
2000 Ω	1 Ω	>4 V	±(1.5 % + 3 digits)
NI-1-			

Note

The number of possible continuity tests with a fresh set of batteries is 3000.

Range R _{LO}	Test Current
7.5 Ω	210 mA
35 Ω	100 mA
240 Ω	20 mA
2000 Ω	2 mA

	Press the $(zero)$ to zero the test probe. Can subtract up to 2 Ω of lead resistance. Error message for >2 Ω .
Live Circuit Detection	Inhibits test if terminal voltage >10 V ac detected prior to initiation of test.

Insulation Resistance Measurement (R_{ISO})

Test Voltages			Accuracy of Test
Model 1651B	Model 1651B		Voltage (at rated test current)
250-500-1000 V	250-500-1000 V	50-100-250-500-1000 V	+10 %, -0 %

Test Voltage	Insulation Resistance Range	Resolution	Test Current	Accuracy
50 V	10 k Ω to 50 M Ω	0.01 MΩ	1 mA @ 50 kΩ	±(3 % + 3 digits)
100 V	100 k Ω to 20 M Ω	0.01 MΩ	- 1 mA @ 100 kΩ	±(3 % + 3 digits)
100 V	20 M Ω to 100 M Ω	0.1 ΜΩ	1 IIIA @ 100 K22	±(3 % + 3 digits)
250 V	10 k Ω to 20 M Ω	0.01 MΩ	1 m A @ 250 kO	±(1.5 % + 3 digits)
250 V	20 M Ω to 200 M Ω	0.1 ΜΩ	1 mA @ 250 kΩ	±(1.5 % + 3 digits)
	10 k Ω to 20 M Ω	0.01 MΩ		±(1.5 % + 3 digits)
500 V 20 MΩ to 200 MΩ		0.1 ΜΩ	1 mA @ 500 kΩ	±(1.5 % + 3 digits)
	200 M Ω to 500 M Ω	1 ΜΩ		±10 %
1000 V	/ 100 kΩ to 200 MΩ 0.1 MΩ		1 mA @ 1 MΩ	±(1.5 % + 3 digits)
	200 M Ω to 1000 M Ω	1 ΜΩ		±10 %
Note The numbe	r of possible insulation tests	s with a fresh set o	f batteries is 2000.	

Auto Discharge	Discharge time constant <0.5 second for C = 1 μ F or less.
Live Circuit Detection	Inhibits test if terminal voltage >30 V prior to initiation of test.
Maximum Capacitive Load: Operable with up the 5 μF load.	

Loop and Line Impedance (Z_I) No Trip and Hi Current Modes RCD/FI

Mains Input Voltage Range	100 - 500 V ac (50/60 Hz)
Input Connection	Loop Impedance: phase to earth
(soft key selection)	Line impedance: phase to neutral
Limit on Consecutive Tests	Automatic shutdown when internal components are too hot. There is also a thermal shutdown for RCD tests.
Maximum Test Current @ 400 V	20 A sinusoidal for 10 ms
Maximum Test Current @ 230 V	12 A sinusoidal for 10 ms

Range	Resolution	Accuracy*
20 Ω	0.01 Ω	No Trip mode: ±(3 % + 6 digits)
20 12	0.01 52	Hi Current mode: ±(2 % + 4 digits)
200.0		No Trip mode: ±(3 %)
200 Ω	0.1 Ω	Hi Current mode: ±(2 %)
2000 Ω	1 Ω	±6 %**

Notes

Prospective Earth Fault Current Test (PSC/IK)

Computation	Prospective Earth Fault Current (PEFC/I _K) or Prospective Short Circuit Current (PSC/I _K) determined by dividing measured mains voltage by measured loop (L-PE) resistance or line (L-N) resistance, respectively.		
Range	0 to 10 kA or 0 to 50 kA (See Power-On Options earlier in this manual)		
Resolution and Units	Resolution	Units	
	I _K <1000 A	1 A	
	I _K >1000 A 0.1 kA		
Accuracy	Determined by accuracy of loop resistance and mains voltage measurements.		

 $^{^*}$ Valid for resistance of neutral circuit <20 Ω and up to a system phase angle of 30°. Test leads must be zeroed before testing.

^{**} Valid for mains voltage >200 V.

RCD Testing

RCD Types Tested

RC	D Type*	Model 1651B	Model 1652B	Model 1653B
AC ¹	G ²	√	√	\checkmark
AC	S ³	√	√	√
A^4	G		√	√
Α	S		V	√

Notes

RCD tests permitted only if the selected current, multiplied by earthing resistance, is <50 V.

Test Signals

RCD Type	Test Signal Description
AC	The waveform is a sinewave starting at zero crossing, polarity determined by phase selection (0 ° phase starts with low to high zero crossing, 180 ° phase starts with high to low zero crossing). The magnitude of the test current is $I_\Delta n \times Multiplier$ for all tests.
A	The waveform is a half wave rectified sinewave starting at zero, polarity determined by phase selection (0 ° phase starts with low to high zero crossing, 180 ° phase starts with high to low zero crossing). The magnitude of the test current is $2.0 \times I_\Delta n$ (rms) x Multiplier for all tests for $I_\Delta n = 0.01A$. The magnitude of the test current is $1.4 \times I_\Delta n$ (rms) x Multiplier for all tests for all other $I_\Delta n$ ratings.

Tripping Speed Test ($_{\Delta}T$)

Current Settings ^[1]	Multiplier	Current Accuracy		
10-30-100-300-500-1000 mA -VAR	X ½	+0 %, -10 % of test current		
10-30-100-300-500-1000 mA -VAR	x 1	+10 %, -0 %		
10-30-100 mA	x 5	+10 %, -0 %		
Note				
[1] 1000 mA type AC only. 700 mA maximum type A in VAR mode.				

¹AC - Responds to AC

²G – General, no delay

³S – Time delay

⁴A – Responds to pulsed signal

^{*}RCD test inhibited for V >265 ac

Current *PCD Typ		Measurement Range		Trip Time Accuracy
Multiplier	Multiplier *RCD Type	Europe	UK	Trip Time Accuracy
X ½	G	310 ms	2000 ms	±(1 % Reading + 1 ms)
X ½	S	510 ms	2000 ms	±(1 % Reading + 1 ms)
x 1	G	310 ms	310 ms	±(1 % Reading + 1 ms)
x 1	S	510 ms	510 ms	±(1 % Reading + 1 ms)
x 5	G	50 ms	50 ms	±(1 % Reading + 1 ms)
x 5	S	160 ms	160 ms	±(1 % Reading + 1 ms)

Notes

Maximum Trip Time

The RCD \checkmark symbol switches on when testing the RCD trip time if the trip time meets the following conditions:

RCD	IΔN	Trip Time Limits
AC,G	x 1	Less than 300 ms
AC, G - S type	x 1	Between 130 ms and 500 ms
Α	x 1	Less than 300 ms
A - S type	x 1	Between 130 ms and 500 ms
AC,G	x 5	Less than 40 ms
AC, G - S type	x 5	Between 50 ms and 150 ms
A	x 5	Less than 40 ms
A - S type	x 5	Between 50 ms and 150 ms

RCD/FI-Tripping Current Measurement/Ramp Test $(I_{\Delta N})$

Models 1652B and 1653B

Current Range	Step Size	Dwell	Measurement Accuracy	
Current Kange	Type G			
*30 % to 110 % of RCD rated current	10 % of I $_{\Delta\mathrm{N}}$	300 ms/step	500 ms/step	±5 %

Note

30 % to 150 % for Type A $I_{\Delta\,N}$ > 10mA, 30 % to 210 % for Type A $I_{\Delta\,N}$ = 10 mA

Specified trip current ranges (EN 61008-1): 50 % to 100 % for Type AC, 35 % to 140 % for Type A (>10 mA), 35 % to 200 % for Type A (\leq 10 mA)

^{*}G - General, no delay

^{*}S - Time delay

Earth Resistance Test (R_E)

Model 1653B Only. This product is intended to be used to measure installations in process plants, industrial installations, and residential applications.

Range	Resolution	Accuracy	
200 Ω	0.1 Ω	±(2 % + 5 digits)	
2000 Ω	1 Ω	±(3.5 % + 10 digits)	

Range: R _E + R _{PROBE} ^[1]	Test Current
2200 Ω	3.5 mA
16000 Ω	500 μΑ
52000 Ω	150 μΑ
Note	
[1] Without external voltages	

Frequency	Output Voltage			
128 Hz	25 V			

Live Circuit Detection detected prior to start of test.

Phase Sequence Indication

Model 1653B Only

Icon	icon Phase Sequence indicator is active.
Display of Phase Sequence	Displays "1-2-3" in digital display field for correct sequence. Displays "3-2-1" for incorrect phase. Dashes in place of a number indicate a valid determination could not be made.
Mains Input Voltage Range (phase-to-phase)	100 to 500 V

Mains Wiring Test

Icons (���, ���, ��০) indicate if L-PE or L-N terminals are reversed. Instrument operation is inhibited and an error code is generated if the input voltage is not between 100 V and 500 V. The UK Loop and RCD tests are inhibited if the L-PE or the L-N terminals are reversed.

Operating Ranges and Uncertainties per EN 61557

		<u> </u>		
Function	Display Range	EN 61557 Measurement Range Operating Uncertainty	Nominal Values	
V EN 61557-1	0.0 V ac – 500 V ac	50 V ac – 500 V ac ±(2% + 2 dgt)	U _N = 230/400 V ac f = 50/60 Hz	
R _{LO} EN 61557-4	0.00 Ω - 2000 Ω	0.2 Ω - 2000 Ω ±(10 % + 2 dgt)	4.0 V dc $<$ U _Q $<$ 24 V dc R_{LO} \le 2.00 Ω I _N \ge 200 mA	
RISO EN 61557-2	0.00 ΜΩ - 1000 ΜΩ	1 MΩ - 200 MΩ ±(10 % + 2 dgt) 200 MΩ - 1000 MΩ ±(15 % + 2 dgt)	U _N = 50 / 100 / 250 / 500 / 1000 V dc I _N = 1.0 mA	
	Z _I (No Trip) 0.00 Ω - 2000 Ω	0.4 Ω - 2000 Ω ±(15 % + 6 dgt)	U _N = 230/400 V ac f = 50/60 Hz I _K = 0 A – 10.0 kA	
Z _I EN 61557-3	Z_I (Hi Current) 0.00 Ω - 2000 Ω	0.2 Ω - 200 Ω ±(10 % + 4 dgt)		
	R _E 0.00 Ω - 2000 Ω	10 Ω - 1000 Ω ±(10 % + 2 dgt)		
$_{\Delta}$ T, I_{Δ} N	$_{\Delta}$ T 0.0 ms – 2000 ms	25 ms – 2000 ms ±(10 % + 1 dgt)	ΔT = 10 / 30 / 100 / 300 / 500 / 1000 / VAR mA	
EN 61557-6	I _{ΔN} 3 mA – 550 mA (VAR 3 mA – 700 mA)	3 mA - 550 mA ±(10 % + 1 dgt)	I _{ΔN} = 10 / 30 / 100 / 300 / 500 / VAR mA	
R _E EN 61557-5	0.0 Ω - 2000 Ω	10 Ω - 2000 Ω ±(10 % + 2 dgt)	f = 128 Hz	
Phase EN 61557-7			1:2:3	

Operating Uncertainties per EN 61557

The Operating Uncertainty shows the maximum possible uncertainty when all influence factors E1-E10 are counted.

	Volts	R _{Lo} EN 61557-4	R _{ISO} EN 61557-2	Z _I EN 61557-3	Δ ^T EN 61557-6	l _{∆N} EN 61557-6	R _E EN 61557-5
Intrinsic Uncertainty A	0.80 %	1.50 %	10.00 %	6.00 %	1.00 %	5.00 %	3.50 %

Influence Quantity	Volts	R _{Lo} EN 61557-4	RISO EN 61557-2	Z _I EN 61557-3	Δ ^T EN 61557-6	l _∆ N EN 61557-6	R _E EN 61557-5
E1 - Position	0.00 %	0.00 %	0.00 %	0.00 %	0.00 %	0.00 %	0.00 %
E2 - Supply Voltage	0.50 %	3.00 %	3.00 %	3.00 %	3.00 %	2.75 %	2.25 %
E3 - Temperature	0.50 %	3.00 %	3.00 %	3.00 %	3.00 %	2.25 %	2.75 %
E4 - Series Interferences Voltage	-	-	-	-	-	-	1.50 %
E5 - Resistance of the probes and auxiliary earth electrodes	-	-	-	-	-	-	4.00 %
E6.2 - System phase angle	-	-	-	1.00 %	-	-	-
E7 - System frequency	0.50 %	-	-	2.50 %	-	1	0.00 %
E8 - System voltage	-	-	-	2.50 %	2.50 %	2.50 %	0.00 %
E9 - Harmonics	-	-	-	2.00 %	-	-	-
E10 - D.C. Quantity	-	-	-	2.50 %	-	-	-

165XB

Users Manual