

## Fluke 320 and 330 Series Clamp Meters

### Technical Data



- **Narrow body and jaw fit into small spaces**
- **Backlight available on most models**
- **Accurate low current measurements**
- **Inrush current feature on most models**
- **Auto shut-off**

#### **New Inrush Feature**

A new innovation from Fluke! Fluke Clamp Meters with the inrush feature measure motor starting current like a circuit breaker or overload unit sees it. One button lets you troubleshoot current surges that can cause nuisance tripping. Fluke's inrush feature gives you a synchronized reading of the current draw profile from motor start up.

For more information about Fluke's new inrush feature go to [www.fluke.com/330](http://www.fluke.com/330) to view *Inrush, A Technology Brief*.

# Choose the model that fits your work.

Looking for a clamp meter that's right for you? Match the functions and features listed below to the Fluke Clamp Meter best suited for your job.

## 321

AC Amps  
Ohms  
AC Volts  
Auto-Off  
Hold  
Compact








## 322

AC Amps  
Ohms  
AC Volts  
Auto-Off  
Hold  
Compact  
**DC Volts**



Measure ac current	400.0 A	40.00 A 400.0 A
Measure ac voltage	400.0 V 600 V	400.0 V 600 V
Measure continuity	$\leq 30 \Omega$	$\leq 30 \Omega$
Measure dc voltage		400.0 V 600 V
Higher resolution for loads below 40 amperes		0 - 40.00A 40.0 - 400.0A
Measure resistance	400.0 $\Omega$	400.0 $\Omega$
Measure inrush		
Work in poorly lit areas		
Measure non-linear loads		
Measure dc current		
Variable speed drives and stand-by power		

333	334	335	336	337
AC Amps Ohms AC Volts Auto-Off Hold <b>Full Size</b> DC Volts	AC Amps Ohms AC Volts Auto-Off Hold Full Size DC Volts <b>In-rush</b> <b>Backlight</b>	AC Amps Ohms AC Volts Auto-Off Hold Full Size DC Volts In-rush Backlight <b>True-rms</b>	AC Amps Ohms AC Volts Auto-Off Hold Full Size DC Volts In-rush Backlight True-rms <b>DC Amps</b>	AC Amps Ohms AC Volts Auto-Off Hold Full Size DC Volts In-rush Backlight True-rms DC Amps <b>Frequency</b> <b>Large Jaw</b> <b>MIN/MAX</b>
				
400.0 A	600.0 A	600.0 A	600.0 A	999.9 A
600.0 V	600.0 V	600.0 V	600.0 V	600.0 V
≤ 30 Ω	≤ 30 Ω	≤ 30 Ω	≤ 30 Ω	≤ 30 Ω
600.0 V	600.0 V	600.0 V	600.0 V	600.0 V
600.0 Ω	6000 Ω	6000 Ω	6000 Ω	6000 Ω
	100 mS	100 mS	100 mS	100 mS
	Backlight	Backlight	Backlight	Backlight
		True-rms	True-rms	True-rms
			600.0 A	999.9 A
				400.0 Hz

**Specifications** (@23 °C + 5 °C RH 0 - 90%)

		<b>Fluke 321</b>	<b>Fluke 322</b>	<b>Fluke 333</b>	<b>Fluke 334</b>	<b>Fluke 335</b>	<b>Fluke 336</b>	<b>Fluke 337</b>
~ <b>A</b>	Range	0 - 400.0 A	0 - 40.00 A 40.0 - 400.0 A	0 - 400.0 A	0 - 600.0 A	0 - 600.0 A	0 - 600.0 A	0 - 999.9 A
	Accuracy	1.8% ± 5 counts (50 - 60 Hz) 3.0% ± 5 counts (60 Hz - 400 Hz)	1.8% ± 5 counts (50 - 60 Hz) 3.0% ± 5 counts (60 Hz - 400 Hz)	2% ± 5 counts (50 - 60 Hz)	2% ± 5 counts (50 - 60 Hz)	2% ± 5 counts (50 - 60 Hz)	2% ± 5 counts (10 - 100 Hz) 6% ± 5 counts (100 - 400 Hz)	2% ± 5 counts (10 - 100 Hz) 6% ± 5 counts (100 - 400 Hz)
	Crest Factor (50/60 Hz)	-	-	-	-	2.4 @ 500 A 2.0 @ 600 A add 2% for C.F.>2	3 @ 500 A 2.5 @ 600 A add 2% for C.F.>2	3 @ 500 A 2.5 @ 600 A 1.42 @ 1000 A add 2% for C.F.>2
	AC Response	Averaging	Averaging	Averaging	Averaging	True-rms	True-rms	True-rms
Inrush	Integration Time	-	-	-	100 mS	100 mS	100 mS	100 mS
- <b>A</b>	Range	-	-	-	-	-	0 - 600.0 A	0 - 999.9 A
	Accuracy	-	-	-	-	-	2% + 3 counts	2% + 3 counts
~ <b>V</b>	Range	0 - 400.0 V 0 - 600 V	0 - 400.0 V 0 - 600 V	0 - 600.0 V	0 - 600.0 V	0 - 600.0 V	0 - 600.0 V	0 - 600.0 V
	Accuracy	1.2% + 5 counts (50 - 400 Hz)	1.2% + 5 counts (50 - 400 Hz)	1% + 5 counts (50/60 Hz)	1% + 5 counts (50/60 Hz)	1% + 5 counts (50/60 Hz)	1% + 5 counts (20 - 100 Hz) 6% + 5 counts (100 - 400 Hz)	1% + 5 counts (20 - 100 Hz) 6% + 5 counts (100 - 400 Hz)
	AC Response	Averaging	Averaging	Averaging	Averaging	True-rms	True-rms	True-rms
- <b>V</b>	Range	-	0 - 400.0 V 0 - 600 V	0 - 600.0 V	0 - 600.0 V	0 - 600.0 V	0 - 600.0 V	0 - 600.0 V
	Accuracy	-	1% + 5 counts	1% + 5 counts	1% + 5 counts	1% + 5 counts	1% + 5 counts	1% + 5 counts
Ω	Range	0 - 400.0 Ω	0 - 400.0 Ω	0 - 600.0 Ω	0 - 600.0 Ω 601 - 6000 Ω	0 - 600.0 Ω 601 - 6000 Ω	0 - 600.0 Ω 601 - 6000 Ω	0 - 600.0 Ω 601 - 6000 Ω
	Accuracy	1% ± 5 counts	1% ± 5 counts	1.5% ± 5 counts	1.5% ± 5 counts	1.5% ± 5 counts	1.5% ± 5 counts	1.5% ± 5 counts
Continuity		≤ 30 Ω	≤ 30 Ω	≤ 30 Ω	≤ 30 Ω	≤ 30 Ω	≤ 30 Ω	≤ 30 Ω
<b>Hz</b>	Range	-	-	-	-	-	-	5.0 - 400.0 Hz
	Accuracy	-	-	-	-	-	-	0.5% ± 5 counts
	Trigger Level	-	-	-	-	-	-	10 - 100 Hz ≥ 5 A 5 - 10 Hz, 100 - 400 Hz ≥ 10 A
MIN/MAX		No	No	No	No	No	No	Yes
Backlight		No	No	No	No	Yes	Yes	Yes
Display Hold		Yes	Yes	Yes	Yes	Yes	Yes	Yes
Size	Height	7.5"	7.5"	9.375"	9.375"	9.375"	9.875"	9.875"
	Width	2.5"	2.5"	3.125"	3.125"	3.125"	3.125"	3.125"
	Depth	1.4"	1.4"	1.625"	1.625"	1.625"	1.625"	1.625"
	Jaw Opening	1"	1"	1.2"	1.2"	1.2"	1.7"	1.7"
Weight		8 oz.	8 oz.	11 oz.	11 oz.	11 oz.	11 oz.	11 oz.

**Models 321 and 322**

**Operating temperature**

-14 °F to 122 °F  
(-10 °C to 50 °C)

**Altitude**

2,000 meters

**Battery life**

(2) AAA carbon zinc approximately 100 hours continuous, automatic low battery indicator

**Safety rating**

IEC 1010-2-031, 600 V CAT III

**Temperature de-rating**

< 18 °C, > 28 °C add 0.1 x specified accuracy / °C

**Storage temperature**

-22 °F to 140 °F (-30 °C to 60 °C)

**Warranty**

Two years

**Models 333, 334, 335, 336 and 337**

**Operating temperature**

-14 °F to 122 °F  
(-10 °C to 50 °C)

**Altitude**

2,500 meters

**Battery life**

(2) AA alkaline approximately 150 hours continuous, automatic low battery indicator

**Safety rating**

IEC 1010-2-031, 600 V CAT III

**Temperature de-rating**

Add 0.1 x specified accuracy for each °C above 28 °C or below 18 °C

**Storage temperature**

-40 °F to 140 °F  
(-40 °C to 60 °C)

**Warranty**

Three years

**Need Technical Assistance?**

Call 1-800-44-FLUKE toll free in the U.S. or (800) 36-FLUKE in Canada or (425) 446-5500 in other countries.



**Fluke. Keeping your world up and running.**

**Fluke Corporation**

PO Box 9090, Everett, WA USA 98206

Fluke Europe B.V.  
PO Box 1186, 5602 BD  
Eindhoven, The Netherlands

For more information call:  
In the U.S.A. (800) 443-5853 or  
Fax (425) 446-5116  
In Europe/M-East/Africa (31 40) 2 675 200 or  
Fax (31 40) 2 675 222  
In Canada (800) 36-FLUKE or  
Fax (905) 890-6866  
From other countries (425) 446-5500 or  
Fax (425) 446-5116  
Web access: <http://www.fluke.com/>